


# SCHEELS®

## Scheels Outfitter A Frame 8' Blind

Thank you for purchasing the Scheels Outfitters A Frame Blind from Scheels.

### Included parts:

6x-Crossbar, 4x-End Uprights, 2x-Bottom End (push pins), 4x-Frame Support, 4x-Door Support Rod, 4x-Gun Rest, 1x-8' Cover, 1x-Carrying Strap



### Assembly:

**Step 1:** Organize like parts together

**Step 2:** Assemble both end frame sections by inserting End Uprights into Bottom End pieces. Attach Frame Supports. Set both end frame sections to the side.

**Step 3:** Join End Frame Sections together using the Crossbars.

**Step 4:** Insert each Door Support Rod into the pocket opening located at each end of the blind cover. Pockets are sewn onto the top side of each end of the blind cover. Simply expose the pocket opening and insert the rod.

**Step 5:** Attach the gun rests to the upper crossbars. The set screw should be secured to the underside of the crossbar.

**Step 6:** Attach each cover section to the frame. One cover has 3 gear pockets located on the inside middle area of the cover. One section does not have any gear pockets. Attach the covers taking into consideration which side you want the gear pockets facing. Each cover has 2 post pockets which go onto the top of the End Upright posts. Attach the Velcro to the frame. Secure the doors using buckles.

**Step 7:** Brush in blind.

**Transportation:** Frame pieces can be rolled up in the covers and carried using the included carrying strap.

**Tip:** DRY Stubble and grass can be left on the covers. Simply roll up the grassed covers and secure. Do not leave wet grass on the covers as mildew can form and ruin the cover.

**If you do have any issues with this product stop in at your local Scheels store or visit [Scheels.com](https://www.scheels.com).**